

SEQUENCING TO MINIMIZE LAPPING IN APPLYING LATEX PAINT TO A PANELED DOOR

The idea is to keep a wet edge while doing all stiles and rails simultaneously. The painter must work quickly and carefully, being sure to keep brush or roller adequately filled, and using just two or three brush strokes per application:

- A. Paint each panel using brush or roller and brush then use either a roller or brush to:
- B. Paint the top rail
- C. Keeping a wet edge, paint all stiles down to just onto the next rail; then
- D. Paint the next rail, keeping a wet edge
- E. Then continue downward on each stile, stopping in the next rail
- F. Etc.
- G. Etc.
- H. Finish by doing the bottom rail.

